


# MICRO TOUCH PINOUT CABLE



PIN 1	PIN 2	PIN 3	PIN 4	PIN 5	PIN 6
NOT CONNECTED	NOT CONNECTED	TO STARGO AUX PIN 1	TO STARGO AUX PIN 2	TO STARGO AUX PIN 3	TO STARGO AUX PIN 4

PIN 1	PIN 2	PIN 3	PIN 4
TO STARGO AUX PIN 1	TO STARGO AUX PIN 2	TO STARGO AUX PIN 3	TO STARGO AUX PIN 4



**NOTE:**  
The Focuser Ascom Driver comes with the StarGO installation and it works by connecting the Micro Touch to Aux1